

# YS170

170 years of knowledge  
pieced together to make  
one lock



See over for operating instructions



The world's favourite lock since 1843

# YS170

To register your YS170 and activate the 10 year mechanical guarantee please visit [www.yale.co.uk](http://www.yale.co.uk)

To ensure that your new multi-point door lock functions correctly please follow the operating instructions below.


## Lever/Lever Operation

### To lock (from inside or outside)

1. Close the door firmly to engage the latch (do not depress handle).
2. Lift the lever up to throw the hooks to locked position
3. Turn the key to deadlock

### To unlock (from inside or outside)

1. Turn the key to unlock the deadbolt
2. Push lever down to disengage the hooks and latch
3. Open the door



## Lever/Lever Night Latch Operation

### To lock (from inside or outside)

1. Close the door firmly to engage the latch (do not depress handle).
2. Lift the lever/pad up to throw the hooks to locked position
3. Turn the key to deadlock

### To unlock (from outside)

1. Turn the key to withdraw deadlock "unlock" (let go of key)
2. Push lever down to disengage the hooks only (let go of lever)
3. Turn key again in same direction to disengage the latch

### To unlock (from inside)


Follow lever/lever instructions above.

### Latch retainment

If your handle is fitted with the optional latch retainer button –

**To hold the latch:** withdraw latch and hold, slide snib on faceplate upwards. Latch is held.

**To release:** Slide snib downwards.



YS170DRHANG

**Yale**<sup>®</sup>

The world's favourite lock since 1843